

Vertical cavity lasers for applied spectroscopy

Alexei Sirbu

A. Mereuta, A. Caliman and E. Kapon

Laboratory of Physics of nanostructures, EPFL, 1015 Lausanne

V.Iakovlev, G. Suruceanu

BeamExpress S.A., 1015 Lausanne

KTI/CTI

SATW

SWISSLASER NET

Outline

SSOM, Engelberg, March 18

- **Laser spectroscopy for sensing:**
 - Fiber-Bragg sensors;
 - Tunable laser diode absorption spectroscopy;
 - Resonant Photoacoustic gas sensors;
- **1500-2000 nm Vertical Cavity Lasers with fundamental mode emission of 1-6 mW;**
- **2 W diffraction limited Vertical External Cavity Lasers in the 1500 nm band.**


Outline

- Laser spectroscopy for sensing applications:
 - **Fiber-Bragg sensors;**
 - Tunable laser diode absorption spectroscopy;
 - Resonant Photoacoustic gas sensors;
- **1500-2000 nm Vertical cavity lasers with fundamental mode emission of 1-6 mW;**
- **2 W diffraction limited Vertical External Cavity Lasers in the 1500 nm band.**

FBG – sensor spectroscopy

The Bragg condition - determines resonance wavelength.


Fiber Bragg grating - couples forward to backward propagating modes.



The resonance peak position depends on temperature and longitudinal strain.

FBG sensors in CH structures (EMPA)

- Stay cable bridge, Winterthur
- Power dam of Luzzone



Figur 4: Bogen-Staumauer Luzzone während der Erhöhung

SMS 7, 1998, Brönnimann et al.

SPIE 3407, 1998, Brönnimann et al.


Surveillance using FBG is **performed periodically** since each time **expensive** FBG interrogation equipment has to be shipped in the field and installed.

Needs for in-situ, light-weight structural monitoring





In-situ longitudinal strain monitoring



FBG-VCSEL sensor system



1560 1564 1568
wavelength, nm



Tunable
laser



VCSEL requirements for portable, in-situ FBG sensing systems

- Wavelength inventory in the 1550 nm band;
- ~1-5 mW fundamental mode emission;
- Wavelength sweep frequency ~ 1 kHz;
- Tuning range ~ 10 nm;
- Line-width ~5 MHz.

SSOM, Engelberg, March 18

Specifications developed in collaboration with Dr. Hans G. Limberger, APL, IMT, EPFL, in the frame of Nanotera Proposal 20NAN1_123588, 2008

VCSEL based FBG systems:

- **light weight** fiber grating interrogation system based on WDM technology;
- **Dynamic in-situ measurements** of temperature and strain during curing of composite materials;
- portable systems for continuous monitoring of **terrestrial, airborne and space** structures.

Letters of support from

- Alinghi

<http://www.alinghi.com/en/>




- Oerlikon space

<http://www.oerlikon.com/space/>




- Endosense

<http://www.endosense.com>



Technology focus on fiber optic sensors

SSOM, Engelberg, March 18



- Distributed fiber optic market estimations:**
- Optoelectronics Industry Development Association (OIDA): \$550 million by 2010.
 - Global Industry Analysts: > \$650 million by 2010.


Outline

- Laser spectroscopy for sensing applications:
 - Fiber-Bragg sensors;
 - **Tunable laser diode absorption spectroscopy;**
 - Resonant Photoacoustic gas sensors;
- 1500-2000 nm Vertical cavity lasers with fundamental mode emission of 1-6 mW;
- 2 W diffraction limited Vertical External Cavity Lasers in the 1500 nm band.

Tunable laser diode spectroscopy in the 1500-2000 nm range



Gas	Symbol	Absorption line, nm
Methane	CH ₄	1650
Ammonia	NH ₃	1512
Carbon Monoxide	CO	1570
Carbon Dioxide	CO ₂	2004, 1953
Water	H ₂ O	2003
Ethylene	C ₂ H ₄	1617
Hydrochloride	HCl	1740

Local gas-cell sensing




Remote sensing of CH₄

Application – WMS (wavelength modulation spectroscopy)



The fine structure of the gas absorption peak consists of single absorption lines.

Example of VCSEL based absorption spectroscopy set-up




Temperature and injection current are controlled to 0.01°C and 1μA

A modulation current is superimposed on the VCSEL drive current for increasing detection sensitivity;

Gas pressure is controlled in the range 1 mbar- 1 bar.

CO₂ detection with LPN/BX VCSEL


SSOM, Engelberg, March 18



Dashed lines— ordinary room air
Solid lines— 10 mbar CO₂
Optical path length - 10 cm

V.Iakovlev, Internal report

Detection limit of micro- Laser Gas Detectors




IR
microsystems
A Leister Company

micro LGD



SSOM, Engelberg, March 18




Laser power ~ 1 mW. Detection limit ~ 0.3 ppm

B. Willing, IRM/Leister, PSE, EPFL


Outline

- **Laser spectroscopy for sensing applications:**
 - Fiber-Bragg sensors;
 - Tunable laser diode absorption spectroscopy;
 - **Resonant Photoacoustic gas sensors;**
- **1500-2000 nm Vertical cavity lasers with fundamental mode emission of 1-6 mW;**
- **2 W diffraction limited Vertical External Cavity Lasers in the 1500 nm band.**

Resonant photo-acoustic spectroscopy




SSOM, Engelberg, March 18



- Modulated light is absorbed by gas molecules and results in a temperature increase and a local pressure raise.
- The sensing cell (~25x15 cm) acts as an acoustic resonator amplifying the signal by more than 500 times.
- Required laser power level 0.5-1 W!

Detection limit, ammonia at 2500 nm



Precision ~ ±0.4 ppb

Dr. Etienne Rochat, Omnisens S.A., Morges, VD

NH₃ Photoacoustic sensor apparatus produced by Omnisens S.A. in Morges



Challenge:

To replace the CO₂ laser by 1512 nm and 1740 nm VECSELS with ~1W diffraction limited output for both NH₃ and HCl trace gas detection

The system is based on a CO₂ laser.

Detection limit 0.1 ppb of NH₃. Application: trace-gas detection in clean-rooms.

Outline

- **Laser spectroscopy for sensing applications:**
 - Fiber-Bragg sensors;
 - Tunable laser diode absorption spectroscopy;
 - Resonant Photoacoustic gas sensors;
 - **1500-2000 nm Vertical cavity lasers with fundamental mode emission of 1-6 mW;**
 - **2 W diffraction limited Vertical External Cavity Lasers in the 1500 nm band.**

Sensing VCSELs important parameters:

SSOM, Engelberg, March 18

- Broadband precise wavelength control;
- High output of several mW;
- Narrow line-width of ~ 5MHz;
- Continuous tuning of ~ 10 nm.

Long-wavelength VCSELS: three main approaches





Table 1 | Current performance of LW-VCSELS

Aperture type	Mirror design	SMP _{max} , 20 °C	SMP _{max} , 80 °C
Undercut QWs	Top and bottom as-grown DBRs: InAlGaAs/InAlAs, or AlGaAsSb	1.6 mW	0.5 mW @ 70 °C
Buried TJ	One as-grown InAlGaAs /InAlAs DBR; one dielectric DBR	4.3 mW	1.4 mW
Regrown TJ	Both wafer-fused AlGaAs/GaAs DBRs	6 mW	2.5 mW

SMP_{max} 20 °C (80 °C), single-mode maximum power output at 20 °C (80 °C); TJ, tunnel junction.; QW, quantum well


E.Kapon, A. Sirbu, Nature photonics, Technology focus, pp.27-29, 2009

1500 nm-2000 nm VCSEL design



4 regions on the wafer with different emission wavelengths

Cavity Mapping of double-fused wafer







Emission at 1550 nm, 1560 nm, 1570 nm, 1580 nm corresponds to off-sets of 30 nm, 40 nm 50 nm 60 nm

A. Sirbu, Invited talk AOE-08, A. Caliman, et al, ECOC-08

1550 nm LI and IV Characteristics (7 μm aperture)



SSOM, Engelberg, March 18



- Max RT output: at 1560 nm (40 nm off-set);
- Max HT (90°C) output: at 1580 nm (60 nm off-set)


LIVs at different emission wavelengths

SSOM, Engelberg, March 18





A. Caliman, To be presented at CLEO-09

Emission spectra vs current



Measurements by V. Iakovlev,



Tuning with current



E. Kapon, Invited talk ISLC-08

1550 nm ar-field emission and line-width

Far-field and line-width measurements performed at 2 mW output, RT



Frequency, MHz

Lorentzian line-shape; $\Delta\nu = 4.5$ MHz

FWHM=9°

Self-homodyne line-width measurements performed by M. Grossenbacher, ED EPFL

Wavelength selection in the 2000 nm band




Figure 1 spectra







Figure 2. LIV of 4 devices



Two-species detection: CO₂ and H₂O



CO₂ and H₂O absorption spectra according to Hitran2k



Wavelength tuning



Wavelength tuning range ~ 5 nm

Single mode emission in the 4-18 mA current range


Wavelength tuning rates:

- $\Delta\lambda/\Delta I \sim 0.31 \text{ nm/mA}$
- $\Delta T/\Delta I \sim 0.14 \text{ nm/}^\circ\text{C}$

Outline

- **Laser spectroscopy for sensing applications:**
 - Fiber-Bragg sensors;
 - Tunable laser diode absorption spectroscopy;
 - Resonant Photoacoustic gas sensors;
- **1500-2000 nm Vertical cavity lasers with fundamental mode emission of 1-6 mW;**
- **2 W diffraction limited Vertical External Cavity Lasers in the 1500 nm band.**


■ VECSEL scheme



VECSELS: circular diffraction limited high power output


M.Kuznetsov, PTL, vol.9, pp.1063-1065, 1997

1550 nm VECSEL half-cavity




A.Sirbu et al., To be presented at OFC-09

1550 nm VECSEL pumping scheme



Output characteristics

SSOM, Engelberg, March 18




x 10 improvement compared with previous published results

J. Rauticainen, J. Lyytikainen, A. Sirbu, A. Mereuta, A. Caliman, E.Kapon, O.Okhotnicov, **Optics Express**, Dec. 2008

Spectral characteristics


SSOM, Engelberg, March 18



Spectra are taken at
10.9 W of 980 nm
pump power.
Shift with
temperature:
0.42 nm/°C

Wavelength combs: multiple reflections in
the diamond heat-spreader

Far-field pattern



SSOM, Engelberg, March 18

Far field pattern distribution measured with a pyrocamera

Summary

- Emerging spectroscopy developments in fiber-bragg sensors, tunable laser diode spectroscopy, and photo-acoustic sensors require laser sources with prescribed wavelengths, continuous tuning, narrow linewidth and high output power in the 1500 nm 2000 nm
- 1500 nm-2000 nm state of the art wafer fused VCSELS demonstrate fundamental mode output of 6+mW, excellent on-wafer wavelength control in the 50 nm band, narrow linewidth of below 5 MHz and continuous wavelength tuning of up to 15 nm. First gas sensing experiments have been successfully performed.
- High power of 2 W+ diffraction limited VECSELS in the 1550 band are demonstrated for the first time. Application in Ph. Application in acoustic sensing to be evaluated.

Thank you for your
attention