
A new era for micro-optics manufacturing: the final frontier ...

Rolando Ferrini

CSEM SA – MicroNano Optics

Swissphotonics Webinar, 03.06.2020



CSEM mission








Development and transfer of world-class (micro-)technologies to the industrial sector – in Switzerland, as a priority – in order to reinforce its competitive advantage.

- Cooperation agreements with established companies
- Encouraging the creation of start-ups



MicroNano Optics at CSEM

Manufacturing by imprint technologies



:: csem

MicroNano Optics at CSEM

Nano- & Micro-optical structures





THE EUROPEAN **PILOT LINE** FOR THE MANUFACTURING OF


FREE- FORM MICRO-OPTICS




Free-form micro-optics

Free-form micro-optics consists of micro-optical component

- **□** with no symmetry restrictions
- ☐ gaining an increasing industrial interests in the last few years











Free-form optics for PICs


- ☐ Folded interconnects: Current solutions
 - Optical connectivity is based principally on collinear solutions
 - Folded connectivity is manly done with additional components, such as parabolic mirrors, optical benches, lens mirror systems etc.





- ☐ Folded interconnects: CSEM solution
 - Operational for all standard telecom optical fibers (SM & MM, 850-1650nm)
 - Integrated micro-optical component
 - Light bending → TIR (Total Internal Reflection)
 - Fiber coupling → Self-alignment micro-structures
 - Wafer-scale compatible












Design & Fabrication



- * $r = 600 \mu m$
- * $r = 780 \mu m$
- Micro-prism:
 - * a = 45 deg; $h = 80 \mu \text{m}$











Prism: Laser micro-fabrication (FEMTOprint©)




Mould tool on structured mask



Lens replication and alignment structures

Single process step




:: csem

Fabricated folded interconnects




□ Replication of Micro-prisms

- without smoothened master → rough surface
- with smoothened master → good surface / rounded edge
 Commercial micro-prism as master benchmark



□ Replications of Q-lens

Nice surface & edges also for the alignment fiber walls









Optical losses & Mode profile





Device	SM loss [dB]	MM loss [dB]
45° Prism (replicated from commercial μprism)	0.35	0.42
Q-lens 600	0.42	0.48
Q-lens 780	0.36	0.38





Results of Q-lens (r=780 μm) with MM as input fiber at different z-distances in comparison to simulations

☐ The optical mode profile and the angular directivity are well maintained







What's PHABULOµS





PHABULO_μS ...

... is the European **one-stop shop** for the manufacturing of **free-form micro-optics**

... offers

- ☐ accelerated innovation & production cycles
- manufacturing services
- ☐ prototyping → piloting → large volume production









« Who »

We are ...










« What »



« How »

Year 1 Year 2 Year 3 Year 4 Beyond

Pilot line Set up Acceleration / Improvement of technologies & processes

Technology validation with use cases

Validation of services with pilot cases & Piloting

Low to full rate pilot production

Pilot line

Management &
Sustainability

Creation the pilot line legal entity & front office

Open calls for pilot cases

Customer outreach


Commercialization & Sustainability





« Why »

Without PHABULOU μ S



With PHABULOU μ S







« For whom »
















Contact us

Dr. Rolando Ferrini
Rue Jaquet-Droz 1
CH-2002 Neuchâtel
Switzerland

+41 79 950 24 69

rolando.ferrini@csem.ch

www.phabulous.eu



