Eurica Eurica


Integrated photonics for scaling trapped ion quantum computing.



Quantum Computing Overview

 THE PROMISE: Massive algorithmic speedup: a quantum computer isn't faster – it simply needs far fewer steps to reach solution.

- THE APPLICATIONS: Drug design, cybersecurity, materials, chemistry....
- PROBLEM: To be useful, QCs need to be able run much larger circuits












The Trapped-Ion Value Prop

Quantum computers need higher qubit quality and quantity

Trapped Ions


QUALITY

QUANTITY



- 'Ideal qubits' not manufactured
- All-all connectivity
- Error Correction/Logical Qubits
- Highest fidelities $\mathcal{F}_{2q} \ge 0.9999$

- 'Only' 50-98 qubits so far
- Already reached the limit of 1D architecture



Trapped Ion Quantum Information group, ETH Zurich



State-of-the-art Trapped Ion QC


The method: Physical shuttle, split, join, rotation operations in RF trap

The cost of all-all connectivity:


Majority of time spent rearranging ions into fixed beam interaction zones

1D: Quantinuum HS1 (20 ions)

Pseudo-2D: Quantinuum HS2 (56 ions)



As of Nov 25, Quantinuum Helios launched with 1 junction and 98 ions



Beam Interaction 7 one


Moses, S. A., et. al. (2023). Physical Review X, 13(4), 041052.

RF electrodes



The Scaling Challenges of RF-Trapped Ion Quantum Computing

- 1-D approaches simply won't scale
- 2-D QCCD is the mainstream roadmap



RF poses significant engineering challenges

- Scalability constrained by RF rails
- Complicates: ease-of-manufacture ease-of-use



The Penning Quantum Computer

INNOVATION


Remove the RF fields; replace with large (~T) static, homogeneous magnetic field

ARCHITECTURE

Trap only with static voltages
2-D grids of ions with higher density
Free rearrangement


BENEFITS


Ease-of-use: no 'traffic jam' at junctions
Ease-of-manufacture: low heating, low voltage
10x larger density – 10'000 ions on cm sized chip.





First micro-Penning trap unit cell









The ZuriQ Scalable Architecture


KEY VALIDATION: From single ion drawing to reconfigurable 2 x 2 array @ ETH Zurich!



Jain, S., Sägesser, T., Hrmo, P. et al. Penning micro-trap for quantum computing. *Nature* **627**, 510–514 (2024).









Integrated Optics for Laser Delivery

PARALLELISM


Waveguides and gratings deliver light to many zones

ALIGNMENT

Electrode-grating alignment is critical. Penning advantage: no need to stay in RF null – bring ions to focus.

STABILITY

Passive phase stability allows for higher fidelity gate operations - standing waves





The Ion Trap Wishlist

- Atomic species dependent wavelengths

 i.e. ⁴⁰Ca+ 375, 393, 397, 729, 850, 854, 866 nm
 ¹³⁷Ba+ 493, 650, 1760 nm
 ⁹Be+ 313 nm
- Variety of beam foci (1 10s µm) and emission angles
- Low losses dissipation in chip highly undesirable
- High intensities faster gate speed
- No exposed dielectric well defined voltage level over gratings
- Light collection gratings, lenses, fibres
- Modulation AM for fast extinction
 PM for frequency sideband generation



Light Collection & Networks

- Quantum links between chips will require photonic information transfer
- Quantum state readout/remote entanglement generation requires high photon collection efficiency. State of the art: 250 Hz, 94% Fidelity (Duke, 2024)
- Fast, localised readout suitable for mid-circuit error detection/correction

Grating collection





Image: Gillen Beck (ETHZ)

Cavity enhanced collection rate




Kassa et. al. Phys. Rev. Applied 23, 024038 (2025)



Light Collection & Networks


New challenges appear when combining these techniques with RF trapping fields.

Grating collection



Knollmann et. al. Collection of fluorescence from an ion using trap-integrated photonics (2025) arxiv.org/pdf/2505.01412

Cavity enhanced collection rate




Kassa et. al. Phys. Rev. Applied 23, 024038 (2025)

No RF micromotion at grating focus and nor RF potential disturbance near cavity shield in Penning traps!



Phase Modulators for Penning

- Large B field leads to big
 Zeeman shifts
- Lasers need high frequency sidebands at 50-150 GHz
- Current solution: fibre EOMs off chip.
- Advantage: spectral separation removes need for polarization purity.



Thank you



www.zuriq.com