Laser dressing of tools

SSOM Engelberg Lectures on Optics

Silvan Roth inspire AG / ETH Zurich



IWF

Institut für Werkzeugmaschinen und Fertigung Eidgenössische Technische Hochschule Zürich Institute of Machine Tools and Manufacturing Swiss Federal Institute of Technology Zurich

Grinding

stock removal grinding

- rough grinding
- high ablation rates
- rough surface ۲

precision grinding

- finish grinding lacksquare
- smooth surface •
- high quality lacksquare
- low tolerances •



inspire.



2






Institut für Werkzeugmaschinen und Fertigung Eidgenössische Technische Hochschule Zürich Institute of Machine Tools and Manufacturing



Swiss Federal Institute of Technology Zurich

Schematic of grinding wheel

inspire




IWF

Eidgenössische Technische Hochschule Zürich Swiss Federal Institute of Technology Zurich

3

Why dressing?




inspire.

4


Institut für Werkzeugmaschinen und Fertigung Eidgenössische Technische Hochschule Zürich Institute of Machine Tools and Manufacturing

Swiss Federal Institute of Technology Zurich

Wearing out of grinding tools




insp/re



Institut für Werkzeugmaschinen und Fertigung Institute of Machine Tools and Manufacturing Swiss Federal Institute of Technology Zurich

Surface situation after grinding: a) undressed grinding wheel, b) dressed grinding wheel Wang et al.: Key Engineering Materials 329, **2007**




decrease of material removal efficiency due to outwearing of the abrasive tool

5

Conventional dressing


- mechanical dressing
- dressing tool (diamond)
- surface of dressing tool
- time consuming (hard materials)
- inefficient: 10% material removal with grinding, 90% with dressing




Laser Fabrication and Machining of Materials, Springer US, 2008



Laser assisted dressing





Zhang, Shin: Int. Journal of Machine Tools and Manufacture, 42, 2002

IWF


- pre-heating of work piece
- softening of material
- easier removal with dressing tool
- weaker forces on dressing tool, increasing life time
- improvement of surface quality



Institute of Machine Tools and Manufacturing


Laser dressing of SiC or diamond grinding wheels

Ablation of the grinding wheel by melting and blow out with ms pulses (Nd:YAG laser, up to 1 kW)



a) exp. setup, b) overlapping of thermal traces on grinding wheel surface

Hosokawa et al: Annals of the CIRP 55, 2006



forces during grinding process

IWF




8

Institut für Werkzeugmaschinen und Fertigung Eidgenö Institute of Machine Tools and Manufacturing Swiss Fe

Eidgenössische Technische Hochschule Zürich Swiss Federal Institute of Technology Zurich

Dressing of Al₂O₃ grinding wheels



Institute of Machine Tools and Manufacturing

Nd:YAG


2.5 kW

50 cm/s

CW

Rapid solidification

- cracking and melting of grains
- fast re-crystallization of the surface
- smoother surface
- bonding between grinding grains
- change of grain shapes



Al₂O₃ Grinding wheel:

10

top before laser dressing, buttom: after laser dressing

ME


Jackson et al: Brit. Ceramic Trans. 102, 2003




Institut für Werkzeugmaschinen und Fertigung Eidgenössische Technische Hochschule Zürich Institute of Machine Tools and Manufacturing

Swiss Federal Institute of Technology Zurich

Reforming of cutting edges and microstructures



Harimkar, et al. : J. Phys. D: Appl. Phys. 39, 2006



Harimkar, Dahotre:Int. J. Appl. Ceram. Technol., 3, 2006


- new regular build vertices and edge
- production of micro cutting edges
- grain size is well controllable





Eidgenössische Technische Hochschule Zürich Swiss Federal Institute of Technology Zurich

Conclusion



- dressing improves surface of tools
- mechanical dressing •rough surface
- laser-assisted dressing
 - weakening of surface
 - smaller forces during processing
- laser dressing
 - cracking and melting of grains
 - re-solidification of grains
 - improvement of surface quality

IWF


- laser dressing of diamond tools diamond is the hardest material
- diamond diamond machining is time consuming
- short pulsed laser ns, ps well controlled ablation, small HAZ
- processing tools with complex geometries beam delivery









Laser ablation on single diamond grain





replica technique



- structuring is possible with nano- and picosecond pulses
- height profiles
- replica technique, pre post processing comparison



IWF

Institute of Machine Tools and Manufacturing



Outlook

- detailed analysis from nano- and picosecond ablation experiments
- determination of ablation rate
- microstructure analysis
 - SEM, Raman
- grinding experiments with processed grains, tools
- integration in process, machine design
- CTI project

